

Amerige Heights' Equipment, Wi-Fi Options and Installation Information

Please review the options below and inform the installation technician of any customizations and/or upgrades you would like before your installation begins.



Core Router (Included, \$0/mo)

The Core Router combines a fiber gateway and Wi-Fi 6 Router, providing wired and wireless Internet connections for residents. It eliminates the need for residents to provide their own router. Additional wired devices can be connected via the 10 Gb Ethernet port and (3) 1 Gb Ethernet ports.



Core Wi-Fi Extender (One-Time Purchase, \$129 each)

The Core Wi-Fi Extender expands Wi-Fi coverage in larger homes by creating an additional Wi-Fi location connected to your Core Router. Please note that the Core Wi-Fi Extender is not compatible with our Bring Your Own Router or Gigabit Wi-Fi Plus options. If you would like to include a Core Wi-Fi Extender in your installation, inform your technician. The Core Router supports up to 3 Core Wi-Fi Extenders, which are exclusively compatible with GigabitNow's Core Router. You can connect them via built-in Ethernet cables or use them wirelessly.



Gigabit Wi-Fi Plus (\$9/mo)

To relocate your Internet connection, connect the additional Gigabit Wi-Fi Plus router to any Ethernet port in your home. Only the 10 Gb Ethernet port will be active, all other ports on the Core Router will be inactive.

Mobile App: Monitor and control your home network from your mobile device, enable parental controls, set up usage restrictions, create guest Wi-Fi networks, and manage your entire home network by tracking devices and individual usage.



Bring Your Own Router (\$0/mo)

All installations in Amerige Heights include the Core Router for the fiber connection. If you prefer to use your own router, inform the technician. Your router can be connected to any Ethernet port in your home for extended Internet. Custom installs vary in price. The Core Router provides 2 Gbps speeds (5 Gbps with the upgraded plan). Under the Bring Your Own Router option, **speeds may be limited by the personal router you choose to use for your home network**. Only the 10 Gb Ethernet port will be active, all other ports on the Core Router will be inactive. Contact GigabitNow for assistance with speed and device inquiries.

Installation Information

The Core Router should be mounted on the wall or placed on a shelf for optimal signal strength. Avoid bending or pinching the fiber optic cable to prevent signal loss. Contact GigabitNow support to switch between Core Router and Bring Your Own Router modes. Residents are responsible for any Core Router damage as it belongs to SiFi Networks. Larger homes and multi-story townhomes may need extenders or mesh routers for complete Wi-Fi coverage. Previous HOA Internet equipment stays in the wiring cabinet. Residents can use their previous HOA Internet as a backup until October 2023.



Amerige Heights의 장비, Wi-Fi 옵션 및 설치 정보

아래 옵션을 검토하고 설치를 시작하기 전에 원하는 사용자 정의 및/또는 업그레이드를 설치 기술자에게 알려주십시오.



코어 라우터 (포함, 월 \$0)

코어 라우터는 파이버 게이트웨이와 Wi-Fi 6 라우터를 결합하여 거주자에게 유선 및 무선 인터넷 연결을 제공합니다. 거주자가 자신의 라우터를 제공할 필요가 없습니다. 추가 유선 장치는 10Gb 이더넷 포트와 (3) 1Gb 이더넷 포트를 통해 연결할 수 있습니다.



코어 Wi-Fi 익스텐더 (1회 구매, 각 \$129)

Core Wi-Fi Extender는 Core Router에 연결된 추가 Wi-Fi 위치를 생성하여 더 큰 집에서 Wi-Fi 범위를 확장합니다. Core Wi-Fi Extender는 Bring Your Own Router 또는 Gigabit Wi-Fi Plus 옵션과 호환되지 않습니다. Core Wi-Fi Extender를 설치에 포함하려면 기술자에게 알려주십시오. 코어 라우터는 GigabitNow의 코어 라우터와 독점적으로 호환되는 최대 3개의 코어 Wi-Fi 확장기를 지원합니다. 내장 이더넷 케이블을 통해 연결하거나 무선으로 사용할 수 있습니다.



기가비트 Wi-Fi 플러스 (월 \$9)

인터넷 연결을 재배치하려면 추가 Gigabit Wi-Fi Plus 라우터를 가정의 이더넷 포트에 연결하십시오. 10Gb 이더넷 포트만 활성화되고 코어 라우터의 다른 모든 포트는 비활성화됩니다.

모바일 앱: 모바일 장치에서 홈 네트워크를 모니터링 및 제어하고, 자녀 보호 기능을 활성화하고, 사용 제한을 설정하고, 게스트 Wi-Fi 네트워크를 만들고, 장치 및 개별 사용을 추적하여 전체 홈 네트워크를 관리합니다.



나만의 라우터 사용 (월 \$0)

Amerige Heights의 모든 설치에는 광섬유 연결을 위한 코어 라우터가 포함됩니다. 자신의 라우터를 사용하려면 기술자에게 알려주십시오. 확장된 인터넷을 위해 라우터를 가정의 모든 이더넷 포트에 연결할 수 있습니다. 맞춤 설치는 가격이 다릅니다. 코어 라우터는 2Gbps 속도를 제공합니다(업그레이드 계획의 경우 5Gbps). 나만의 라우터 사용 옵션에서 홈 네트워크에 사용하도록 선택한 개인 라우터에 의해 속도가 제한될 수 있습니다. 10Gb 이더넷 포트만 활성화되고 코어 라우터의 다른 모든 포트는 비활성화됩니다. 속도 및 장치 관련 문의는 GigabitNow에 문의하십시오.

설치 정보

코어 라우터는 최적의 신호 강도를 위해 벽에 장착하거나 선반 위에 놓아야 합니다. 신호 손실을 방지하기 위해 광섬유 케이블을 구부리거나 조이지 마십시오. 코어 라우터와 나만의 라우터 사용 모드 간에 전환하려면 GigabitNow 지원팀에 문의하십시오. 거주자는 SiFi Networks에 속한 코어 라우터 손상에 대한 책임이 있습니다. 더 큰 집과 다층 타운 홈에는 완전한 Wi-Fi 범위를 위해 익스텐더 또는 메시 라우터가 필요할 수 있습니다. 이전 HOA 인터넷 장비는 배선 캐비닛에 그대로 있습니다. 거주자는 2023년 10월까지 이전 HOA 인터넷을 백업으로 사용할 수 있습니다.

